

USER MANUAL



M01

www.fslscoreboards.com

info@fslscoreboards.com

+44 (0)28 8676 6131



Sports Technology Solutions

Discover more at www.fslscoreboards.com

know the score...


1) Scoreboard connections:

- The scoreboard should be supplied with a 230V mains supply.
- The mains supply should be fed through a 5 amp circuit breaker and it is highly recommended that the supply should be fed through a Residual Current Device (RCD)
- If the scoreboard has been supplied with a separate aerial this should be mounted as high as possible

2) On Power Up:

- 'Cd - ' will be displayed for 5 seconds
 - This is a "code" number stored in memory
 - There are 5 possible codes that may be used, this allows a number of displays to be operated in close proximity of each other
 - Further details on programming the code can be found at the end of the manual
- The scoreboard will now go into normal operation, displaying scores with the clock blanked.



3) Changing Scores:


1. To increase the score press the  button







2. To decrease the score press the  button




3. To clear the score press the  &  button together





4) Brightness Setting:

- To access brightness setting, hold buttons  &  on the handset together for 3 seconds until 'bl - ' is displayed
- To exit brightness setting, hold buttons  &  on the handset together for 3 seconds until the scores are displayed again





Increasing Brightness:



- While 'bl - ' is displayed, increase brightness with button 
- The maximum brightness is 9




Decreasing Brightness:

- While 'bl - ' is displayed, decrease brightness with button 
- The minimum brightness is 0



- To exit brightness setting, hold buttons  &  on the handset together for 3 seconds until the scores are displayed again

- 6) Scoreboard Blank:



To blank the scoreboard display, press the  & . The score will be restored if any score button is pressed.



FSL ELECTRONICS LTD
SANDHOLES ROAD
COOKSTOWN
CO TYRONE
N. IRELAND
BT80 9AR
+44(0)28 86766131
www.fslelectronics